CHEUY II / NOVA







Complete Kits - Gen IV SureFit

961164 1962-65 Nova Complete Kit 961166 1966-67 Nova Complete Kit 965069 1968 Nova Complete Kit (factory air) 961069 1968 Nova Complete Kit (non-factory air) 965072 1969-72 Nova Complete Kit (factory air) 961072 1969-72 Nova Complete Kit (non-factory air)

Evaporator Kits - Gen IV SureFit (See page 13)

561164 1962-65 Nova Evaporator Kit 561166 1966-67 Nova Evaporator Kit 565069 1968 Nova Evaporator Kit (factory air) 561069 1968 Nova Evaporator Kit (non-factory air) 565072 1969-72 Nova Evaporator Kit (factory air) 561072 1969-72 Nova Evaporator Kit (non-factory air)

Gen IV Sure Fit™ System Features:

- Fly-By-Wire fully electronic servo motor controls with no cables or capillary tube to route.
- Infinite "just right temperature" air blending.
- Infinite blower fan speed adjustment (3-speed on 68-72 with factory air controls).
- High-volume dehumidified defrost mode.
- Separate high-capacity aluminum plate & fin cooling coil.
- Copper/brass CuproBraze™ parallel flow heater coil.
- Mounts behind the dash.
- Uses your factory system controls with our patented Electronic Cable Converters (66-72).
- New in-dash rotary controls, with 3 OEM style fluted aluminum knobs, included (62-65).
- Flat steel firewall cover panel.
- Replacement molded glove box (reduced capacity).



TOTALLY COOLED GALLERY

Randy Johnson at D&Z Customs built this beautiful '66 Nova for his wife, Tobie. It features a serious LS 1, full Heidt's Pro-G suspension, Wilwood brakes and huge Forgeline 18 inch wheels. The body remains 90% original, including the paint! To keep his customer cool and comfortable, Randy installed a complete Gen IV SureFit system too!



Complete Gen IV kit for 1966-67 Nova

Complete Gen IV kit for 1969-72 Nova

NOTES:

- 1. Some installations may require additional engine pulleys not included with kits. You must provide pulleys, V-belts, heater hose and refrigerant. See Page 81 for Chevy pulleys.
- 2. We recommend using our heavy duty fan blade and **32069-VCF** (1966-67 Nova) shroud.
- 3. SureFit systems may interfere with some OEM radios or in-dash speakers.



1966-67 kits include our exclusive, Electronic Cable Converters™ to adapt your car's control panel.

NOTE:'66-67 Control panel not included! Photo shows the Cable Converters used to adapt YOUR panel to the system.

Optional System Components



627902 Non-air stamped firewall blockoff plate. '67-'69 Camaro, '64-'72 Chevelle & '68-'74 Nova



1962-65 Chevy II dash using our rotary controls.



1966-67 Nova dash using factory controls.



1969-72 Nova factory air dash.



1969-72 Nova non-factory air dash.

CUSTOMER SERVICE TEAM

Wayne Potter, Senior Sales Associate, has been around hot rods his entire life. Wayne has an extensive automotive background and his current project is a 1968 C10 while he enjoys crusing around in the familys 1966 chevy II. Both rides keeping cool with Vintage Air SureFit systems.

